


## Instructions for meter reading retrievals on Ricoh MFP's

Step 1: Press the 123 (User Tools/Counter) button (usually located top left hand corner of operation panel)

Step 2: Select the counter button on the display



Step 3: Select "Print Counter List"

